



Diversey Oxivir · SmartDose system

Oxivir Plus

Broad-spectrum disinfectant cleaner — 1.4L

AHP technology **5 min** **No rinse**

hydrogen peroxide-based contact time breaks down to water & oxygen

Oxivir Plus is a broad-spectrum, one-step cleaner and disinfectant based on Diversey's Accelerated Hydrogen Peroxide (AHP) technology. It's effective against bacteria, viruses (including coronavirus and norovirus) and fungi, and is safe on all acid-resistant surfaces including upholstery and carpets. Ideal for outbreak prevention and body spillage clean-up. It's dosed through the SmartDose bottle system.

Before you start

- The concentrate is acidic — wear gloves and eye protection when handling it or fitting a new SmartDose bottle.
- **Not suitable for marble or aluminium** — these are acid-sensitive materials.
- No rinsing needed — the active ingredient breaks down to water and oxygen after use.
- Fragrance-free and dye-free.
- For professional/trade use only.
- Store away from extremes of temperature.
- Full safety information is in the product's Safety Data Sheet — ask us if you need a copy.

How to use it

The SmartDose bottle doses itself as you fill it — no measuring needed.

● Cleaning & disinfecting a surface

- 1 Fill a 750ml spray bottle with water.
- 2 Turn the yellow head to the spray-bottle setting, pull it up fully, then press down to dose the concentrate into the bottle.
- 3 Shake gently before use.
- 4 Pre-clean heavily soiled areas first.
- 5 Spray onto the surface, making sure it's thoroughly wet, and wipe with a cloth.
- 6 Leave the surface wet for **5 minutes** contact time.
- 7 Wipe dry or allow to air dry — no rinsing needed.

Change the solution once it looks visibly dirty or diluted.

Product details

Format	SmartDose bottle (1.4L)
Technology	Accelerated Hydrogen Peroxide (AHP)
Effective against	Bacteria, viruses, fungi
Contact time	5 minutes

Surface compatibility: all acid-resistant surfaces, including upholstery and carpets (WoolSafe approved). Not suitable for marble or aluminium.